

INSTALLATION INSTRUCTIONS

Pedestal Corner Basin • Model #09-300

Please read and understand these instructions BEFORE attempting to install sink.
[Special instructions for installing without pedestal or backsplashes are in brackets.]

- 1• Unpack sink, pedestal, backsplash tiles, hanger brackets and plywood backing boards. Save all packing materials, should return be necessary.
- 2• Test fit sink to pedestal in the corner you plan to install the unit. Do not use backing boards or backsplash at this time. Carefully level both sides of sink along wall. Mark top of sink on wall. (Mark will be concealed by backsplash tiles.) [If sink was purchased without pedestal, the top of the sink is recommended to be 34-1/2" up from the floor.]
- 3• Screw the two 1/2" plywood backing boards horizontally in corner with the top edge 1/2" below mark. The 45° bevels should meet in corner. [If the sink is installed without backsplash, the backing boards are not required.]
- 4• Screw the two hanger brackets to the lower left and lower right corners of the backing boards using the bottom holes only. (Only two screws per bracket at this time.) [If not using backsplash, screw hanger brackets directly to wall. The bottom of the brackets is recommended to be 29-1/2" up from floor. Outermost edges should be 10-1/2" from corner.]
- 5• Reinstall sink and pedestal to test for proper placement. Hanger brackets will "give" a little until final screws are secured in step 9. The pedestal is designed to slide out from under the sink should future repairs be necessary. If sink does not sit properly, readjust hanger brackets. [Without pedestal, sink will be "front heavy". Steps 7 & 10 will fix this problem.]
- 6• Once you've determined the sink will sit properly, remove sink and install drain, valves and supply tubes.
- 7• Apply silicone adhesive to upper half of backing boards [or directly on wall] and place unit in corner for the final installation. Apply silicone adhesive to back of backsplash tiles and slide into position behind sink and on top of backing boards.
- 8• Check one last time for proper placement of sink, pedestal and backsplash. Sink top should be reasonably level. Pedestal base should be equidistant from both walls and backsplash even in corner and at right and left edges of the sink.
- 9• The final two hanger bracket screws can now be secured in the upper holes. (One more screw per bracket.) DO NOT OVER TIGHTEN.
- 10• One more screw is required through the sink at the back corner. Use the rubber washer supplied. Again, DO NOT OVER TIGHTEN as this will tend to pull the sink out of place.
- 11• Use grout or silicone to seal between sink and backsplash [or wall].